



# Technology Helper

---

## **Reprogramming Your Cordless Mouse or Keyboard**

1. Press the LEARN button on the small blue box with the antenna attached to your computer for at least 2 seconds. The green light should blink.
2. Press the TEACH button on the keyboard or the bottom of the mouse and release.
3. The green light on the antenna box should blink rapidly.
4. Your device should now work properly.